



Fluxaf Carpet Glue Remover

Fluxaf Carpet Glue Remover is a powerful remover for various types of glue on carpets. Fluxaf Carpet Glue Remover is less harmful to the environment than conventional carpet glue removers and its unique formula makes it long-lasting.

Application:

Removes stubborn glue residues from carpet floor coverings, textile and vinyl wall coverings.

Instructions:

Carpet

1. First cut the carpet into strips, pull off and roll up.
2. Apply generous amounts of adhesive residue, allow to work in for approx. 30 minutes and remove with a spatula or scraper. Repeat the treatment if necessary.
3. After removing, clean the surface with soap and water, rinse with water and allow to dry thoroughly.

Vinyl

1. If the floor covering is difficult to pull off, first punch it with a pinhole roller or similar tool, apply plenty of primer, allow to work in for approx. 30 minutes and remove with a putty knife or scraper. Repeat the treatment if necessary.
2. After removal, clean the surface with soap and water, rinse with water and allow to dry thoroughly.

Textile and vinyl wall coverings

1. Remove textile and vinyl wallcoverings.
2. Apply a generous coat of adhesive residue and allow to soak in for approx. 30 minutes, then remove with a spatula or scraper. Repeat the treatment if necessary.
3. After removal, clean the surface with soap and water, rinse with water and allow to dry thoroughly.

Please note! Always do a test area first to see if you get the desired finish. This can differ per surface. In case of extreme layer thickness, the product may require a longer penetration time.

Cleaning:

Clean tools with water and soap.

Available quantities:

1L.

Shelf life:

At least 24 months, if stored in a dry, cool and frost-free place in unbroken, original packaging.

Safety advice:

For detailed safety information, refer to the MSDS.

MSDS can be downloaded from www.fluxaf.com.