






Cabinet 3 Door


Art.nr./Nr. de Article :
Wit/Blanc/Weiß




Cabinet 3 Door




70x 450 x 1496
1x




30 x 450 x 738
1x




30 x 450 x 738
1x




30 x 445 x 550
1x




25x 463.5 x545
1x



25x 463.5 x545
2x




86x 450 x1440
1x



4 x 1468 x 548
1x




30 x 30 x 157
1x



Ø5 x 33 mm
20x




Ø15 x 12 mm
20x




Hinges
6x




TJF Ø6 x 16mm
24x




Ø8 x 30 mm
20x



TJP Ø6 x 12mm
22x




Handle
3x



TJF Ø6 x 19mm
6x






TIPPING HARDWARE
1x




FISHER S6
1x

Cabinet 3 Door




Cabinet 3 Door

3



4



Cabinet 3 Door

- 5

C

6X



D

12X



G


3X



H

6X






- 6

F

22X










Cabinet 3 Door

7

D
12X



8



Cabinet 3 Door

9

I

1X

J

1X

This inset diagram shows a close-up of the hinge assembly, labeled 'I', being attached to the inner edge of the cabinet door. An arrow indicates the direction of assembly.

J

The main assembly diagram shows the cabinet door being attached to the main cabinet frame. A callout box indicates the hinge location. The cabinet has a wire mesh front panel on the right side.