




JOY

Item number: 15500/02/33
 EAN code: 54 1121215 1964

A


Firstly, charge the lamp until the led change to green. The USB cable is in the attachment bag. We recommended that you use 1A adaptor.

Red (Charging)	Green (Full)
	



B

Secondly, to turn on/off the lamp, please touch the switch on the top.



C

The lamp is dimmable.

