



S700 SERIE








**HANDLEIDING
GUIDE D'INSTALLATION
USER MANUAL**

**ROLHOR
VOOR DEUREN**

**MOUSTIQUAIRE ENROULABLE
POUR PORTES**

**ROLLER SCREEN
FOR DOORS**


TOOLS



(3 mm) **A**



3,5x16 mm (4x) **C**




(2x) **B**



(2x) **D**



1x




1x




2x


G











E 2x



F








6a


(ENKELE DEUR / PORTE SIMPLE / SINGLE DOOR)



$L = X + 10 \text{ mm} = \dots\dots\dots \text{ mm}$


6b

(DUBBELE DEUR / PORTE DOUBLE / DOUBLE DOOR)




$L = X / 2 = \dots\dots\dots \text{ mm}$


7




8






9




10






16



17



Service

123100450



123100451 (wit)
123103414 (zwart)



123100452



123100454 (wit)
123103413 (zwart)

