#### 423518601

# UK SRG-00022 / 2017-07 Original instruction manuals and safety regulations are available at Boels Verhuur B.V.

## SUBMERSIBLE PUMP 4 M<sup>3</sup>

#### Instructions for Use and Safety

The water pump is intended for pumping water from underground spaces such as cellars, garages, etc. Use water pump for water level of minimum 7 mm to max. 3 m.



#### Caution!

Improper operation can injure the user or damage the device. Read the safety instructions first!

# SAFETY INSTRUCTIONS



#### Safety for user

- · Beware of infection! If necessary, take hygienic and sanitary precautions.
- Always use earthed electrical outlets.
- Keep children and pets out of reach of the machine.
- Use outdoors; Check that the device is connected via a ground leakage switch (max. 30 mA).

#### Check before use

- · Device visually on defects.
- · Electric power and power cord.
- Contact your rental company should you encounter problems with the machine!

#### Safety during use

- Never lift the device using the power cord.
- Never pull the power cable to move device.
- Check water level during use. Never allow the pump to run dry.
- · Handle the plug and power cord carefully.
- Never use the device with a damaged plug or power cord.
- Using an extension cable. Avoid power loss, use at minimum a 2.5 mm thick cable and keep the cable as short as possible. Unroll the cable all the way out.

#### Safety after operating

- After use remove the electric plug from the wall socket
- · Allow residual pressure to escape from the drain hose.

# **1. OPERATING FUNCTIONS**



A Plug / power cordB Drain hose

C Water hose connection D Handle

## **2. PREPARATION FOR USE**



Do not plug A into the power 1 socket

- Connect **B** to **C** 2
- Place pump on flat surface 3 Caution! Optionally lower or lift the pump with a rope attached to **D**!

# **3. USE WATER PUMP**



#### Plug A in a grounded electrical 1 socket

- Pump area empty. Check water level during use. Caution! Minimum water level is 7 mm!
- Remove A in time from the 3 power outlet Caution! Never allow the pump to run dry.

# 4. AFTER USE

- 1 Let any residual pressure escape via B
- Disconnect B 2
- 3 Clean water pump